









FOUR KEY TESTS: Validating MOSFET Performance in Power Supply Designs

TEST SPECIFICATIONS	Drain Family of Curves	Threshold Voltage	Gate Leakage	Transconductance
	<p>Definition: Transistor output characteristics plotted as I_{DS} versus V_{DS} for several values of V_{GS}.</p> <p>Measurement Parameter: I_{DS} vs. V_{DS}</p> <p>Importance in Device Selection: By looking at these curves, the designer can determine the best operating point for the application. At low drain-source voltages, the MOSFET behaves like a variable resistance whose value is controlled by the applied gate-source voltage. At higher drain-source voltages, the MOSFET passes a current whose value depends on the applied gate-source voltage. In most circuits, it is used in this 'high voltage' region and acts as a voltage-controlled current source.</p> <p>Test Technique:</p> <ol style="list-style-type: none"> Step the gate voltage (V_{GS}) across the desired range of values at specified increments. At each V_{GS} value, V_{DS} is swept across the desired V_{DS} range. Measure the drain-source current (I_{DS}) at each V_{DS} increment. 	<p>Definition: The minimum gate-to-source voltage differential required to produce current flow from the source to drain.</p> <p>Measurement Parameter: V_{TH}</p> <p>Importance in Device Selection: Threshold voltage is important for determining the on-state and the off-state of the MOSFET. $V_{GS(th)}$ is defined where $V_{DS} = V_{GS}$, although it is sometimes quoted for a fixed V_{DS} (e.g. 10 V.)</p> <p>Test Technique:</p> <ol style="list-style-type: none"> Sweep the gate voltage (V_{GS}) while the drain-source voltage (V_{DS}) is set to a particular value. Measure the drain current (I_D) at each value incremental of V_{GS} in the sweep. Determine the threshold voltage (V_{TH}) through a linear curve fit. A linear region on the curve is selected. The interception of the voltage axis gives the threshold voltage. 	<p>Definition: Transistor gate leakage current as a function of the gate voltage.</p> <p>Measurement Parameter: I_G vs. V_G</p> <p>Importance in Device Selection: The gate leakage current is important when calculating how much current is required to keep the device turned on. Because it is a leakage current through an insulator, this current is independent of temperature.</p> <p>Test Technique:</p> <ol style="list-style-type: none"> Sweep the gate voltage (V_G) over the desired range while the drain and source are tied to common. Measure the gate current (I_G). 	<p>Definition: The change in the drain current divided by the small change in the gate/source voltage with a constant drain/source voltage.</p> <p>Measurement Parameter: I_D vs. V_{GS}</p> <p>Importance in Device Selection: Transconductance helps the engineer to choose the best MOSFET with the right amount of gain (amplification) for the designs.</p> <p>Test Technique:</p> <ol style="list-style-type: none"> Sweep the gate voltage (V_{GS}) over the desired range, while maintaining a constant drain/source voltage (V_{DS}). Measure the drain current (I_D) at each increment step of V_{GS}. Calculate transconductance (g_m) by dividing the small changes in I_D by the small changes in V_{GS}. $g_m = \Delta I_D / \Delta V_{GS}$.
TEST CONFIGURATION				
TYPICAL RESULTS	<p>n-MOSFET Drain Family</p> 	<p>n-MOSFET Threshold Voltage-Linear</p> 	<p>n-MOSFET Gate Leakage Current</p> 	<p>n-MOSFET Transconductance MAX Gm and Threshold Voltage</p> 



Four Key Tests for Validating MOSFET Performance in Power Supply Designs

POSTER

Contact Information:

Australia 1 800 789 465	Austria 0800 255 4835
Balkans, Israel, South Africa and other ISS Countries 41 52 675 3777	Belgium 0800 255 4835
Brazil +55 (11) 3759 7627	Canada 1 800 833 9200
Central Europe / Baltics 41 52 675 3777	Central Europe / Greece 41 52 675 3777
Denmark +45 80 88 3401	Dominican Republic 450 80 88 3401
Egypt 41 52 675 3777	Finland +41 52 675 3777
France 0800 255 4835	Germany 0800 255 4835
Hong Kong 1 800 829 5835	India 000 000 650 1835
Indonesia 007 803 601 5249	Italy 0800 255 4835
Japan 81 (3) 6714 3010	Luxembourg 41 52 675 3777
Mexico, Central/South America and Caribbean 52 650 56 04 50 90	Malaysia 1 800 22 55835
Middle East, Asia, and North Africa 41 52 675 3777	New Zealand 1 800 00 2328
The Netherlands 0800 255 4835	Norway 1 800 00 0948
People's Republic of China 1 800 829 5835	Philippines +800 160 0377
Poland +41 52 675 3777	Portugal 80 08 12370
Rep. of Korea +82 2 8911 5000	Russia CIS 7 395 6647764
Singapore 1 800 601 473	South Africa 41 52 675 3777
Taiwan 886 (2) 2555 6888	Spain 0800 255 4835
Thailand 1 800 011 1931	Sweden 0800 255 4835
United Kingdom / Ireland 0800 255 4835	Switzerland 0800 255 4835
USA 1 800 833 9200	Vietnam 1 2090 128

* European toll-free number. If not accessible, call +41 52 675 3777.

